

## Kalibreringsprotokoll av handskanner Datalogic 2D skanner

1.



Enter/Exit Programming Mode

2.



Country Mode = Sweden

3.



I 2 of 5 = Enable

4.



Set AIM ID Individually for GS1-128 = Disable

5.



Set Global Suffix

6.



0

7.



9

**8.**



Enter/Exit Programming Mode

**9.**



Enter/Exit Programming Mode